
# 90\*120mm



## iBELL 🗀

Technology evolves at an amazing pace, surprising us with gadgets surpassing our imagination. To stay in sync with changing times and present customers with the latest innovations at affordable prices assert the competence of a company. iBell, the consumer durables brand from India, has earned the recognition and trust of millions of customers by presenting them with the newest in home appliances. The brand provides high quality, long-lasting products at favourable prices and effective after-service.

Unlike many other brands iBell has a wide variety of products under its label, ranging from electronics appliances to kitchenware. The brand is further diversifying its product lines in order to serve the overall requirements of a family.

التقنية تتطور تدريجيا بخطوات مدهشة، يعجبنا بأدوات فوق خيالنا. الوقوف مزامنا مع تغيير الأوقات والعملاء الحديثة مع ابتكارات الحديثة بأسعار معقولة، وهذه هي تتاكد كفاءة الشركة. آيييل كعلامة التجارية لأدو اتالمستهلك من الهند قد اكتسبت تقدير وثقة مليونات من العملاء بتقديمهم احدث لوازم المنزلية. نتوفر الشركة منتجات عالية الجودة وطويلة المدى بسعر معتدل و خدمات فعالة بعد البيع.

تتميز شركة أيبيل من علامات تجارية أخرى بسلاسل المنتجات المنتوعة العديدة تحت علامتها التجارية تتراوح من منتجات إلكترونية إلى لوازم المنزلية. وتنتوع الشركة خطوط المنتجات لكي تخدم جميع المتطلبات العائلية. **RECHARGEABLE LIGHT USER MANUAL** 

Name of parts

Name of parts 1)Handle 2) Rear main body

3)Power cord storage cover 4)SMD Tube 5)Reflector

7)Charging indicator 8)Switch 9) Front main body

How to use

■ Using as an emergency light.With 3.7V Li-ion Rechargeable Battery

1.Turn off the light.

2.Plug into AC outlets.(220-240V,50/60Hz)

3.The EMERGENCY LIGHT starts recharging its battery automatically. (Indicator on the switch is red during the charging, turns green after fully charged)

4. The EMERGENCY LIGHT lights automatically whenever power fails.

5. Charge fully for about 8 hours before the initial use. 6.Charge fully after using the EMERGENCY LIGHT before storage.

7.Charge fully at least every three months during storage

 NEVER attempt to disassemble or tamper the EMERGENCY LIGHT.
NEVER insert metal objects between gaps or spaces of the EMERGENCY LIGHT. 3.DO NOT cover the EMERGENCY LIGHT with towels, clothes, ect.

4.DO NOT use the EMERGENCY LIGHT in damp locations or under high humidity. 5.DO NOT use or place the EMERGENCY LIGHT near heating devices or under direct

This Appliance is intended to be used in household and similar applications such as :

-staff kitchen areas in shops, offices and other working environments, farm houses, by clients in hotels, motels and other residential type environments. Bed and breakfast type environments.

## Safety Instructions

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerninguse of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the

## Cord replacement Instructions

If supply cord is damaged, it should be replaced by the service agent,

manufacturer or similarly qualified person.



PRODUCT RANGE (Sur ) PEDESTAL FAN VACUUM CLEANER HIGH PRESSURE CLEANER

3

