


TROLLEY SPEAKER

IBL TY 350DJ



USER GUIDE

Read the manual carefully before use



Technology evolves at an amazing pace, surprising us with gadgets surpassing our imagination. To stay in sync with changing times and present customers with the latest innovations at affordable prices assert the competence of a company. iBell, the consumer durables brand from India, has earned the recognition and trust of millions of customers by presenting them with the newest in home appliances. The brand provides high quality, long-lasting products at favourable prices and effective after-service.

Unlike many other brands iBell has a wide variety of products under its label, ranging from electronics appliances to kitchenware. The brand is further diversifying its product lines in order to serve the overall requirements of a family.

Specification:

- *Frequency Response:40Hz–20kHz
- *S/N Ratio:≥75dB
- *Separation:≥50dB
- *Speaker:10"x 1 + 1"x 1
- *Output Power:50W
- *Power Supply: DC 15V 2A

Caution:

- 1.The power cord cannot be squeezed, pulled, bent, knotted, hanging heavy objects or trampling. To prevent the insulating layer of the power cord getting damaged and cause electric shock.
- 2.Do not place non-liquid or flammable materials around machine or moisturized the machine to prevent electric shock, fire, explosion or other dangerous.
- 3.Never try to block the cooling holes of the machine to cause heat adverse and affect the service life of the machine.
- 4.If the machine suddenly smokes or other anomalies, please unplug the power cord quickly, to avoid causing an accident, and contact your local dealer for repair.
- 5.Without using the machine for a long time ,please unplug the power cord to prevent lightning stroke to get burned.


Inside Package:

TrolleySpeaker	1pc
User's Manual	1pc
Remote	1pc
Wireless microphone	1pc
Warranty card	1pc

How to use the BT:

1. Select the audio input to BT status.
2. Search BT device with name "IBELL" .
3. Connect the BT.
4. If your BT device below 2.0 version, input password "0000" when connecting.

Top panel



Top panel

AUX----- AUX input.

U DISK-----USB socket.

TF CARD-----TF Card socket.

GUITAR IN----Guitar Input.

MIC 1-----MIC 1 socket.

MIC 2-----MIC 2 socket.

DC IN-----DC input.

POWER----- Power switch.

TREBLE----- TREBLE Volume to boost & attenuation of the key.

MASTER VOL--Volume to boost & attenuation of the key.

BASS-----BASS Volume to boost & attenuation of the key.

GUITAR VOL-- GUITAR Volume to boost & attenuation of the key.

MIC VOL----- MIC Volume to boost & attenuation of the key.

ECHO-----ECHO Volume to boost & attenuation of the key.

CH-/|◀◀-----Previous song in USB/SD mode.
Previous saved channel in FM mode.

CH+/>▶▶----- Next song in USB/SD mode.
Next saved channel in FM mode.

INPUT----- Input function key.

AUTO/▶|I -----Play/Pause in USB/SD mode.
Automatic FM radio search by pressing 3 secs.


EQ----- Sound choices.

RECORD----- Recording key.

REPEAT-----REPEAT key.

MIC PRIORITY-----Microphone priority key.


How to use the remote control



- ⏻-----Power switch button(standby) switch
On or off for waiting or On condition.
- USB----- USB Disk
- CARD-----CARD Input
- FM-----FM Input
- AUX-----AUX Input
- BT-----BT Input
- EQ ----- Sound choices
- TUNE-/+----- Decrease/Increase FM frequency in FM mode
- ⏪----- Play/Pause in USB/TF mode.
AUTO Automatic FM radio search by pressing 3 secs.
- ⏮-----Previous song in USB/TF mode
CH- Previous channel in FM mode
- ⏭----- Next song in USB/TF mode
CH+ Next saved channel in FM mode.
- MIC PRIORITY --Microphone priority key
- SAVE -----Save FM Channel
- DISP+/- -----Lightness adjust key
- RECORD -----Record key
- REC.PLAY ----Play recording key
- VOL+/- -----Turn up or turn down the master volume
- Press any key to choose the song
- RESET ----- When the volume is at the maximum, press
"RESET" button.at the status while power on.
- REPEAT-----Repeat key

*If the Remote Control can not function, it is because the battery of remote control has been used up. Thank you.

System connection diagram



FM ANT -----FM radio antenna

LIGHT ON/OFF-----Light ON/OFF

DC 12V IN----- Direct Current 12V Input

Note: Move the antenna in various directions until the clearest signal is received. Keep the antenna as far away as possible from the TV, VCR or any radiation source to prevent unwanted noise.

How to use the recording function

Recording and playback function REC/REC_PLAY

1. Recording microphone:

Plug in the microphone to the mic input or open the wireless microphone, insert U disk or TF card, and then press the “RECORD” switch on the machine or remote, the display will show recording seconds, and then displays the time recording state.

(You can press the recording button to pause it).

2. AUX input signal recording:

First insert U disk or TF card, then press INPUT/ST.BY button go the AUX mode, AUX input signal, and then press “RECORD” switch on the machine or remote, then U disk or TF card will correspond the recording state by flashing.

After the completion of the recording, press the “REC_PLAY” key on the remote to play the recorded audio.

Then press the “REC_PLAY” key to exit the tape to play other songs.

NOTE:

1. Only AUX input or karaoke mode, according to REC (sound recording) can be recorded, and then press REC_PLAY key to play the recording file.

The other mode this button has no effect.

2. MIC_PRIORITY:

In karaoke mode press the MIC_PRIORITY key, will give priority to the microphone sound, other audio input will automatically become small voice; and then click the MIC_PRIORITY button, to cancel the microphone priority.

Note: During music play, using a microphone karaoke accompaniment, master volume reduced to half of the music, 3 seconds without a sound. System will automatically back to the original music volume.

CUSTOMER CARE CENTER

For any query or concerns related to the after sales service, you may please contact us on the number or email mentioned below

**Tel: 0484 - 2922600 / 2620012
1800 120 555 999**

E-mail : service@ibellsworld.com

Web : www.ibellsworld.com

iBELL[®] 
Complete Home Solution